
List of figures

Figure 1	
MICB card in the Meridian 1 system	5
Figure 2	
MICB block diagram	11
Figure 3	
NT5D51 MICB card	14
Figure 4	
Call routing with chairperson access	17
Figure 5	
Installing a PCMCIA card into the MICB faceplate slot	23
Figure 6	
Main Menu	37
Figure 7	
System Administration menu	38
Figure 8	
System Maintenance menu	55
Figure 9	
Protected Administration menu	60
Figure 10	
Conference Administration menu	64
Figure 11	
Conference Maintenance administration menu	69
Figure 12	
Port Maintenance menu	76

Figure 13	
Report Generation menu	78
Figure 14	
Terminal connection to the IPE module I/O panel 50-pin connector .	88
Figure 15	
Terminal connection through the Ethernet Adapter	91
Figure 16	
Maintenance terminal connection to the wall-mounted cabinet	94
Figure 17	
PCMCIA disk audio file structure	112